



Replacement bulbs for the microsunXL are available by calling **937-552-2424** or online at **microsun.com**.

- **PN 9080** - microsunXL Center LED Bulb
- **PN 9085** - LED Side Socket Bulbs

CARE AND USE INSTRUCTIONS:

- Do not open the module. There are no serviceable parts inside.
- Always unplug the lamp from the wall outlet before changing bulbs.
- Never leave any sockets empty when lamp is plugged in.
- Fabric shades should only be vacuumed. Do not attempt to wash or dry clean fabric shades.
- Wood, brass or other lamp bases should be cleaned with normal dusting. Do not use any type of abrasive cleaners or chemicals on any lamp body.

Your Microsun Lamp is under warranty for 5 years, and you have 30 days to return your lamp for any reason by following the enclosed return policy.

Please reach out to us if you have any questions; we are happy to help.



937-552-2424

7890 CENTER POINT 70 BLVD
DAYTON, OH 45424



<https://microsunlamps.com/product-category/microsun-xl>

OWNER'S MANUAL

Congratulations! You now own Microsun's most robust and efficient lighting system ever. The microsunXL provides over 7,200 Lumens of bright, clear, healthy light at a crisp 4000K color temperature for optimal clarity, contrast and color rendition.

The **fully dimmable all-LED** microsunXL is paired with a **wireless remote control**, and is the only Microsun lamp family with a premium **five-year warranty**.

We invite you to visit the Resource Center for supplemental information about your new microsunXL. See QR code on back page or this link: <https://microsunlamps.com/resource-center/>

NOTE: The microsunXL is for INDOOR USE ONLY!

INSTALLING BULBS / REPLACING BULBS:

CAUTION: When installing bulbs, unplug the lamp from the wall outlet to avoid arcing. If light bulbs are hot to the touch, please allow bulbs to cool before handling. Do not operate this lamp with missing bulbs or parts.

LIGHT OUTPUT / ENERGY:

The microsunXL includes a proprietary three (3) bulb system: One (1) microsunXL Center Socket LED bulb that emits over 4000 lumens and two (2) specialty side-socket LED bulbs emitting 1600 lumens each, for a total lamp output of over 7200 lumens of crisp, clear, TruFull Spectrum™ light - perfect for working, reading or a bright, cheerful room ambience.



Assembling the microsunsXL system:

Unpack all contents of the boxes and make sure the following parts have been included and are in good condition:

- Lampshade (1)
- Lamp Body with microsunsXL Module (1)
- microsunsXL Center LED Bulb (1)
- LED Side Socket Bulbs (2)
- Harp & Finial Set (1)
- Wireless Remote System with Manual (1)




STOP! MAKE SURE THE microsunsXL LAMP IS UNPLUGGED BEFORE STARTING THE INSTALLATION.

STEP ONE:

Installing the harp

Squeeze the harp together and insert into harp slots (see Figure 1). Pull up gently to secure harp into sockets. You will feel the harp click into place.




CAUTION: The microsunsXL housing contains no user serviceable parts. Do not open the housing.

STEP TWO:

Installing the microsunsXL bulbs


- Ensure all switches are off and the lamp is unplugged from the wall.
- Install the microsunsXL bulb into the center vertical socket (See Figure 2).
- Install two LED side bulbs into the two angled side sockets.



STEP THREE:

Illumination power and dimming

- The center bulb is powered by the right switch and the two side bulbs are controlled by the left switch.
- Flip both switches to the "ON" position to operate the lamp using the remote dimmer. To bypass the dimmer and use the lamp switches, plug the lamp directly into a wall outlet.




STEP FOUR:

Connecting the wireless remote

- Remove tab from the remote.
- Plug receiver into wall outlet.
- Plug your lamp into the receiver's outlet.

Please review the detailed instructions included with the Wireless Remote System to power the microsunsXL and control brightness levels.

Figure 4



microsunsXL
REMOTE DIMMER